

# 1 Water supply.

Turn **OFF** the water supply to the refrigerator from the home valve.

---

# 2 Empty the tub.

Dispense water from the system to empty the tubing (approximately 50 seconds).

---

# 3 Remove old filter.

Remove the old cartridge. Rotate the knob of the cartridge counter clockwise. When the cartridge is removed it will click out of place. Pull out the cartridge.



# 4 Install new filter.

Take the new cartridge out of its packaging and remove protective cover from the o-rings. With cartridge knob in the vertical position, push the new filter cartridge into the cover until it stops.



# 5 Flush with water.

Turn the refrigerator's water supply back **ON**, and flush 2.5 gallons of water through the filter before use (dispense for approximately 5 minutes).